

Assembly Instructions for Hickory, Barnwood, Frontier and Beetle Kill Pine Log Beds

Parts needed:

- 1 – Log Headboard w/Hardware attached
- 1 – Log Footboard w/Hardware attached
- 1 – Bundle of 5 Slats
- 10 – Screws for Slats
- 8 - Washers
- 8 – 3/8” x 1 1/2” Roundhead Bolts & Nuts for rail attachment
- 2 – Side Rails (77” Long for Single & Double Beds & 83” Long for King & Queen Beds)
- 1 – T-Support (King & Queen Beds Only) – (consists of qty 2 approx 7”x75” boards)

Tools Needed for Assembly:

- Cordless Drill with Phillips Head
or a Phillips screw driver
- 2-9/16” Wrench or Socket

READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING ASSEMBLY

(Note: Do NOT remove the foam coverings on the bottom of the Posts until ready for assembly.)

- 1) Begin by attaching the rails to the hardware on the headboard. The rails fit on the outside of the bracket and will line up with the holes provided. Insert the 3/8” x 1 1/2” bolts through the rail and the bracket. Place washer on bolt next to bracket then tighten the nuts securely onto the bolts with a 9/16” wrench or socket.
- 2) Repeat step one on the footboard end of bed. Tighten all bolts securely.
- 3) If you have a King or Queen Size Bed, assemble the (consists of qty 2 approx. 7”x75” boards – 1 has a slot) – stand the other upright in the slot and screw together – approx height will be 8.25”. Lay assembled T-Support on the floor in the center of the bed running from head to foot and centered between the two side rails. The bed is ready for slats.
- 4) Lay all 5 slats onto the side rails, evenly spaced from head to foot. Secure the slats with the 10 screws provided. Do not over-tighten the screws as this will cause the slats to split.
- 5) Your bed is now completely assembled and ready for use.

Enjoy your new bed for a lifetime!
